



# ART-DEBLOCKER-M

---

MANUAL DEBLOCKING FOR ART-BLOCKED LENSES



High-pressure water jet for lens deblocking.



Quickly separates lens and ART block-piece.

## ART-DEBLOCKER-M

Manual, compact, ART lens deblocking technology. The ART-Deblocker-M uses high-pressure water-jet to separate lens, block-piece, and adhesive after surfacing. It is the perfect solution for labs with low to mid volume manufacturing requirements.

## FEATURES + BENEFITS

- Quickly separates lens and block-piece with the same water-jet technology used in the automated ART-Deblocker-2.
- Simple mechanical adjustment for different block curvatures.
- Easy operation and maintenance.
- Closed water cycle reduces water usage.

## TECHNICAL SPECIFICATIONS

|                           |  |
|---------------------------|--|
| <b>Productivity</b>       | Up to 100 lenses/hour  |
| <b>Working range</b>      | Plano up to +15 dpt base curve<br>Prism up to 5°<br>Progressives, multi-focals, single vision lenses |
| <b>Lens material</b>      | All standard organic materials   |
| <b>Dimensions (wxdxh)</b> | 768 x 735 x 1539 mm<br>30 x 29 x 61 inches   |
| <b>Weight</b>             | 225 kg / 496 lb  |



All technical data subject to change without notice. Verify details with Satisloh.

## CONTACT

**Satisloh AG**  
Neuhofstrasse 12  
CH - 6340 Baar  
Switzerland  
Phone: +41 (0) 41766 16 16  
Email: info@satisloh.com

www.satisloh.com

### North America

### Europe

### Asia

### Central & South America

**Sales**  
**Phone:** +1 262 255 6001  
**Email:** info.usa@satisloh.com  
**Phone:** +49 (0) 6441 912 0  
**Email:** info.de@satisloh.com  
**Phone:** +852 27 56 7711  
**Email:** info.asia@satisloh.com  
**Phone:** +55 (11) 2930 8600  
**Email:** info.latam@satisloh.com

**Service**  
**Phone:** +1 262 255 6001  
**Email:** service.usa@satisloh.com  
**Phone:** +49 (0) 6441 912 222  
**Email:** service.de@satisloh.com  
**Phone:** +852 27 56 7654  
**Email:** service.asia@satisloh.com  
**Phone:** +55 (11) 2930 8600 (pt)  
**Phone:** +57 300 798 3374 (es)  
**Email:** service.latam@satisloh.com

**satisloh**®