

900-TLX

MID-SIZE BOX COATING SYSTEM WITH REVOLUTIONARY SECTOR DOME DESIGN



Optical Manufacturing Solutions.





Revolutionary 3 sector lens holding system

Electron beam aun, thermal source, Ion gun, movable shields for meissner trap

900-TLX

Satisloh's 900-TLX AR box coater produces up to 129 lenses/hour. Utilizing a revolutionary new sector dome design with adaptive rings, the 900-TLX achieves the most efficient result in capacity and productivity for mid-size coaters. The turbo pump keeps energy consumption low while its intuitive design, software and serviceability are user-friendly.

FFATURES + BENEFITS

- High efficiency producing up to 129 lenses/hour (with ringless 3 sector dome). Lowest costs per lenses per hour
- Higher productivity thanks to faster pumping and short process time
- Revolutionary sector dome design can accommodate different sector types at once: sector and standard rings with adaptive rings – increases production capacity and flexibility
- New Turbo-molecular pump included (magnetically levitated) is extremely easy to operate and have low maintenance requirements reducing production stops
- A portable degassing system eases the chamber cleaning process
- MES-360 Lite included, provides daily reports using pre-established KPI to track machine utilization, production throughput, and top five errors. Upgrade to the full MES-360 system as your lab needs change
- Optional: STEP maintenance program ensures your Satisloh coater will perform at the highest quality level for years to come

TECHNICAL SPECIFICATIONS



All technical data subject to change without notice. Verify details with Satisloh



Portable degassing system

OPTIONS

User-friendly HMI software, con-

nectivity Lab 4.0 readv

Tooling solutions

- 3 sector dome (standard with rings, ringless with adaptive rings, ringless)
- Batch with mixed sectors



Satisloh AG		
Neuhofstrasse 12	North America	Telephone:
CH- 6340 Baar		Email:
Switzerland	Europe	Telephone:
Telephone: +41 (0) 41766 16 16		Email:
Email: info@satisloh.com	Asia	Telephone:
		Email:
www.satisloh.com	Central & South	Telephone:

America

CONTACT

info.de@satisloh.com one: +852 27 56 7711 info.asia@satisloh.com ne: +55 (11) 2930 8600 info latam@satisloh.com Fmail

+1 262 255 6001

info.usa@satisloh.com

+49 (0) 6441 912 0

Sales

Service +1 262 255 6001 service.usa@satisloh.com +39 02 33 55 66 77 service.it@satisloh.com +852 27 56 7654 service.asia@satisloh.com +55 (11) 2930 8600 (pt) +57 300 798 3374 (es) service.latam@satisloh.com

satisloh